



Operating a Honda/Acura compatible Digital Media Player

① Setting the audio mode for stereos with 6 Disc buttons.

Put the head unit into CD changer mode by pressing the CD button

② Using the SSA/Voice Interface.

- A. The PhatBox uses the 6 DISC buttons as "mode" buttons.
 - Button 1 activates track browsing
 - Buttons 2 through 5 are Browse Modes
 - Button 6 lists features
- B. Use the TRACK FORWARD or TRACK BACKWARD buttons to find the next **Selection** in a **Mode**.
- C. Push the Track button (the DISC 1 button) and then use the TRACK FORWARD or TRACK BACKWARD buttons to advance through the **Tracks** within your **Selection**.
- D. After 5 seconds of song play the PhatBox will automatically toggle into track browsing mode. You can then use the SEEK toggle button to advance through the **Tracks** within your **Selection**.



Honda Accord stereo pictured may not be identical to your stereo and is shown only as an example