



Operating a Nissan/Infiniti compatible Digital Media Player

1. Setting the audio mode.

Put the car stereo head unit into CD changer mode by pressing the CD button.

2. Using the SSA/Voice Interface for stereos with 6 DISC buttons.


A. The PhatBox uses the 6 DISC buttons as "mode" buttons.

- Button 1 activates Track Browsing Mode
- Buttons 2 through 5 are Browse Modes (listed below)
- Button 6 lists features

B. Use the NEXT TRACK or PREVIOUS TRACK buttons to find the next **Selection** in a **Mode**.

C. Push the Track Mode button (the DISC 1 button) and then use the TRACK FORWARD or TRACK BACKWARD buttons to advance through the **Tracks** within your **Selection**.

D. After 5 seconds of song play the PhatBox will automatically toggle into track browsing mode. You can then use the SEEK toggle button to advance through the **Tracks** within your **Selection**.



Nissan stereo pictured may not be identical to your stereo and is shown only as an example